


MOV-652



1. White(two pins): Audio Output(only for MOV-652)
2. Red RCA GPS Audio Input
3. Yellow RCA AUX Video Input
4. Yellow RCA GPS Sync
5. Red RCA GPS Input
6. Green RCA GPS Input
7. Blue RCA GPS Input
8. White(three pins):to IR receiver(only for MOV-652)
9. Blue DVD/DVT_IR
10. Black: Grounding (GND)
11. Red: ACC (12V+)
12. Yellow: BATT (12V+)
13. Green Park (12V-)(Brake)
14. White: Reverse (12V+)
15. Yellow:RCA :CCD CAMERA (rear camera)

Remote Control



1. **Power** – On/Off Power
2. **AUX/F** – Video Source Switching.
3. **Function** – OSD Function Menu
4. **Arrow** – User Selection

Operation

Power

Press the power button to switch on the power. To make the monitor pop down, press the power button again. Press the power for two seconds to switch off the power.

Input Source Selection

Press the AUX/F button to switch between sources. AUX → GPS → AUX

OSD Menu

Press the OSD function key to adjust the following functions: Brightness, Color, Contrast, Tint, Light, Rev, Mode, Buzzer, Volume, OP/CL. Press the up or down keys to select the function. Press the left and right keys to adjust the function.

Brightness	Brightness Of Picture
Color	Color Density of Picture
Contrast	Contrast of Picture
Tint	Tint of Picture
Light	Brightness of Backlight: Auto, Low, High
Rev	Image Rotation: Mirroring Function REV1, REV2, REV3, REV4
Mode	Display Mode: Normal, Zoom, Wide, Full
Buzzer	On/Off
Volume	Off, Low, Mid, High
OP/CL	Auto On Function Allows Monitor To Rise Automatically When ACC Is On: Off, Auto